



JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

# **How to REMOVE a Sink Faucet!**



JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

# How to REMOVE a sink faucet!

## TOOLS!

Hands!

Adjustable Wrench!







JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

# How to REMOVE a sink faucet!

## Parts!









JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

## How to REMOVE a sink faucet!

1. Locate the hot and cold water shut off valves (D) under the sink. Turn both knobs to the RIGHT to turn off.

NOTE: If your valves are STILL leaking after Step 1, you will need to turn off the water to the whole house by turning off the main water shut off for the house.





JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

## How to REMOVE a sink faucet!

2. Unscrew the water lines (C) from the valves or adapters.








JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

## How to REMOVE a sink faucet!

3. Unscrew any plastic brackets (B) holding the faucet down onto the sink/vanity top/countertop. Lift faucet (A) out.





JD's Turn Keys  
301.704.9434  
[justin@jdsturn-keys.com](mailto:justin@jdsturn-keys.com)

## **How to REMOVE a sink faucet!**

**CONGRATS! YOU HAVE JUST  
REMOVED YOUR  
FIRST FAUCET!!**

**GIVE YOURSELF A  
PAT ON THE BACK!  
WOOT WOOT!**